

EC-410 & EC-410A Instructions

This adapter kit is designed to use the 67-72 Mustang master cylinder, Raybestos Part #MC-36251 or equivalent. This is a dual reservoir disc/drum master cylinder.

- Remove the stock early Ford master cylinder, push rod and dust boot. Install the boot and push onto the Mustang cylinder.
- Insert the two 1 ½" long bolts into the holes in the adapter for the master cylinder. Do not attach the master cylinder yet.
- Mount the adapter to the early Ford master cylinder mount using the three 1" bolts provided. Tighten bolts securely.
- Attach Mustang cylinder to the adapter with the two 1 ½" long bolts previously installed. Secure with two ¾" locknuts provided.
- Adjust pushrod to desired length and re-attach to brake pedal. Don't forget the cotter pin.

NOTE: EC-410A uses ALL 1 ½" long bolts.

1/2/2019