

EC-430

Instructions

This bracket is designed to use a standard 67-72 Mustang disc/drum master cylinder, Raybestos Part #MC36251 or equivalent.

- 1) Remove the stock master cylinder and pedal assembly from the vehicle.
- 2) Disconnect the master cylinder pushrod from the brake pedal arm and remove the pedal pivot shaft lock pin. Disassemble the pedal(s) and shaft from cylinder.
- 3) Re-install the pedal(s), shaft and lock pin onto the master cylinder bracket.
- 4) Install the jam nut and heim end onto the new master cylinder pushrod provided.
- 5) Install the rubber boot supplied in the kit onto the master cylinder and bolt the cylinder to the bracket using two 3/8" x 1 1/2" bolts and locknuts.
- 6) Install the pushrod into the master cylinder and attach to the brake pedal with a 3/8" x 1 1/2" bolt flat washer and locknut. Install the flat washer on outside and heim end.
- 7) Bolt the entire assembly into the car using the two 3/8" x 1" bolts and locknuts.

12/11/2018