

## **EC-440**

### **Instructions**

This bracket is designed to use a standard 67-62 Mustang disc/drum master cylinder, (Raybestos Part #MC36251 or equivalent). It can be used on an automatic transmission car only.

- 1) Remove stock master cylinder and pedal assembly from the vehicle.
- 2) Disconnect the master cylinder pushrod from the brake pedal arm and remove the pedal pivot shaft lock pin. Disassemble the pedal(s) and shaft from cylinder.
- 3) Drill and tap the end of the brake pedal pivot shaft from the 3/8"-16 x 1" bolt provided.
- 4) Re-install the pedal onto the master cylinder bracket and retain with the 3/8"-16 x 1" bolt, lockwasher and flat washer provided.
- 5) Install the jam nut and heim end onto the new master cylinder pushrod provided.
- 6) Install the rubber boot supplied in the kit onto the master cylinder and bolt the cylinder to the bracket using two 3/8" x 1 1/2" bolts and locknuts.
- 7) Install the pushrod into the master cylinder and attach to the brake pedal with a 3/8" x 1 1/2" bolt, flat washer and locknut. Install flat washer on outside of heim end.
- 8) Bolt the entire assembly into the car using the two 3/8" x 1" bolt and locknuts.

12/11/2018